

# QUICKSTART "BASIC" GUIDELINES FOR STANDARD MODEL 6050/6100 - FOR GATES UP TO 10 FEET AND OPENING 90°




120 S. Glasgow Avenue  
Inglewood, California 90301  
U.S.A.



**Models 6050/6100 is intended for installation only on swing gates used for vehicles.**  
Pedestrians must be supplied with a separate access opening.

For safety and installation instructions, please refer to the Installation/Owner's manual.

## Operator Position




## Concrete Position



## High Voltage Connection

**GATE OPERATOR MUST BE PROPERLY GROUNDED!!**

**Tip:** It is recommended that a surge suppressor be installed on the high voltage power lines.



**Important:** The elbow assembly must be in the correct position on the arms **BEFORE** cycling operator the first time.

## DIP-Switch Settings

Using shadow loop and gate opening in direction shown.

