

297C
Carry Bar

Certification:	ANSI/BHMA A156.3 Type #27
Projection:	25/32” (20 mm)
Base:	1-3/4” x 2-1/4” (45 mm x 57 mm)
Materials:	Brass and stainless steel
Finishes:	USP, US3, US10, US10B, US15, US32, US32D
Fasteners:	Two (2) 12-24 x 3/4” PPHMS w/ sex nuts
Notes:	• Used when it is possible for the inactive door to be opened before the active door • For use on pairs of doors with astragals • For use in conjunction with a 297D or 298D coordinator • Prevents damage to the doors and other hardware • Carry bar is not required when the inactive door is equipped with automatic or self-latching flushbolts • Non-handed



297D
Coordinating Device

Certification:	ANSI/BHMA A156.3 Type #21A
Base:	1-5/8” x 5/8” (41 mm x 16 mm)
Maximum Astragal Overlap:	1” (25 mm)
Stop Height:	5/8” (16 mm)
Materials:	Steel
Finishes:	Black Prime Coat
Fasteners:	Seven (7) 12-24 x 1-1/4” TPHMS and four (4) #8 x 1” FPH combo screws
Notes:	• For use with overall frame widths 60” (1524 mm), 72” (1829 mm), or 96” (2438 mm), consult Hager Customer Service if overall frame width is different than our stock sizes • Coordinating device is 52” (1321 mm) long for all stock sizes 60” (1524 mm), 72” (1829 mm), or 96” (2438 mm) • Filler bar is cut to length by factory to match customers overall frame width • Non-handed • Designed for use on pairs of doors when one door needs to close before the other • Active door lever, located nearest to the active stop, holds the active door open until the trigger mechanism is released by the closing of the inactive leaf • Coordinator may not span the entire length of stop, 297F filler bar may be needed to fill up the extra space • Compatible with flushbolts • Optional mounting brackets 297M and 297N may be used when mounting other soffit applied hardware • For use with active door widths 30” (762 mm) – 48” (1219 mm) • If active and inactive doors are unequal in length, consult Hager Customer Service for proper sizing • Do not use spring hinges with coordinating device

