

Architectural Door Accessories

ASSA ABLOY

Pemko Door Bottoms

The global leader in
door opening solutions


Applies to the following door bottom:

345_V, 345

Installation Instructions:

1. For outswinging doors, measure, mark and trim rain drip to full width of door. For inswinging doors, trim to clear door stops.
2. Close door and position rain drip along outside bottom edge of door. Be certain rain drip clears threshold (or floor). Mark door in center of slotted holes.
3. Drill pilot holes in door at marks.
4. Secure rain drip to door with supplied screws.

Tools Required:



www.pemko.com

MEMPHIS, TN USA VENTURA, CA USA VANCOUVER, BC CA TORONTO, ON CA
P: 800 824-3018 P: 800 283-9988 P: 877 535-7888 P: 877 535-7888
F: 800 243-3656 F: 800 283-4050 F: 877 535-7444 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DB12_WEBINS
Rev 2 - 03.07.17
Page 1 of 1