Architectural Door Accessories

Pemko Siliconseal[™]

Applies to the following adhesive gasketing product:




Adhesive Gasketing

About Astragals and Meeting Stiles Seals:

Astragal and Meeting Stile seals are used to seal the gap between a pair of doors.

- Adhesive backed.
- High temperature silicone.
- Self-extinguishing and non-toxic.
- Longest-lasting commercial grade door seal.
- Seals against smoke, fire, air, sound and weather.
- Unaffected by sunlight, ozone and ultraviolet rays.
- Impervious to fungus and mildew.
- Excellent compression; door latches easily.




Product / Available Finishes:

S772D Dark Brown Silicone

S772W White Silicone

Tools Required:





Adhesive backing makes installation fast and easy.



The global leader in door opening solutions

Testing/Ratings:
Gasketing material for fire doors intended for aplication to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes. (Thresholds may or may
not contain gasketing material).

4L10

Architectural Door Accessories

Pemko Siliconseal[™]

The global leader in door opening solutions

ASSA AR

Read Before Instructions

Read before installation! Failure to do so may result in improper adhesion.

Storage and shelf life: All adhesive gaskets have a limited shelf life. This product must be used within 6 months of purchase and must be stored between 50°F and 100°F.

<u>Before installing</u>: Thoroughly clean the frame with the enclosed cleansing towelette to remove grease, dust or cleanser build-up. Before installation, wait for frame surface to completely dry (evaporate). Some hospital environments have wax or anti-bacterial cleanser build-up. As an alternative or substitute cleanser, use isopropyl (rubbing) alcohol. Note: Mineral spirits or other petroleum based cleaning products should NOT be used.

<u>Application temperature</u>: If frames are too cold (below 50°F) or too hot (above 100°F) adhesion may be impaired.

When to install:

- Installation should take place after construction is completed, flooring is installed and final cleaning is completed.
- Paint on frame must be cured for at least 5-7 days. Paint cannot be wet under dry surface when gaskets are pressed on. Avoid quick-dry primers, which leave a powdery surface preventing sufficient adhesion. When applying to a wood frame, the surface must be non-porous and sealed. Follow standard industry guidelines on sealed wood frames and/or rough surface before applying. Note: Anti-bacterial, anti-fungal or silicone additives in paint may inhibit adhesion.

Application tips and warnings:

- Do NOT stretch material. Product can retract or shrink if stretched.
- Use very firm, perpendicular pressure when applying. Use wallpaper seam roller to reinforce adhesion after applying.
- Do not stretch material when using seam roller. Run roller with up and down motions.
- Double check adhesion after 2-3 hours before leaving job overnight.
- If gasket separates from frame, press again with firm pressure in place. If adhesive strip is exposed, airborne dust may impede adhesion. Replacement may be necessary.
- Application at header can be awkward due to overhead condition. Be sure to apply enough pressure.

<u>NOTE</u>: Adhesion takes delayed set. Immediate removal and resetting can be done if error occurs in initial placement. DO NOT reset after one hour. Full set is reached in 24 hours.

Installation Instructions


- 1. Pre-cut material equal to height of the door.
- 2. Remove approximately 24" (61 cm) of backing from the adhesive gasketing strip. Be careful not to touch adhesive or drag the adhesive on ground.
- 3. Position the adhesive gasketing as illustrated on the lower left. DO NOT STRETCH MATERIAL. The use of a hand roller is highly recommended.
- 4. Remove the next 24" (61 cm) of paper backing and repeat (2.) until the entire length is installed. If a pre-cut length is too long, stretching has occurred. Immediately remove and reset.
- 5. Once installed, apply firm pressure along the entire surface of the product to ensure proper adhesion to the frame!

Architectural Door Accessories

Pemko SiliconsealTM

The global leader in door opening solutions

Installation Instructions Cont.



Application is acceptable on active or inactive leaf of a pair of doors.

 MEMPHIS, TN USA
 VENTURA, CA USA
 VANCOUVER, BC CA
 TORONTO, ON CA

 P: 800 824-3018
 P: 800 283-9988
 P: 877 535-7888
 P: 877 535-7888

 F: 800 243-3656
 F: 800 283-4050
 F: 877 535-7444
 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

