

# Architectural Door Accessories

**ASSA ABLOY**

## Pemko Door Bottoms

The global leader in  
door opening solutions

Applies to the following door bottom:

**234\_V, 234\_PK, 209\_V**

### Installation Instructions:

1. To install, door must be removed.
2. Measure, mark and trim door bottom shoe to full width of door.  
Trim seal 1/16' longer than trimmed door shoe at each end.
3. Remove vinyl.
4. Fasten door bottom shoe to bottom of door with supplied screws.
5. Replace vinyl. Crimp ends to secure insert.

### Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.

(Thresholds may or may not contain gasketing material).



### Tools Required:



[www.pemko.com](http://www.pemko.com)

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.  
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DB2\_WEBINS  
Rev 2 - 03.07.17  
Page 1 of 1