Architectural Door Accessories

Pemko Perimeter Gasketing

Applies to the following products:

305SSR, 319SSN (PG)

Installation Instructions:

PERIMETER GASKETING:

Please note: This package contains 1 short (header) piece and 2 long (jamb) pieces of weatherstrip. For ease of installation, install header piece first, then 2 jamb pieces.

- 1. Can be installed on a wood or metal frame.
- 2. Measure, mark and trim header piece to length. Close door and position header piece on header stop so that seal makes light even contact with door. Mark header stop in center of slotted holes.
- 3. Drill pilot holes in header stop at marks.
- 4. Secure header piece to header stop with supplied screws.
- 5. To install the 2 jamb pieces, repeat steps 2, 3, and 4. Jamb pieces should contact threshold (or floor) at bottom & contact header piece at top.
- 6. Open and close door several times to check jamb weatherstrip fit and seal, and to make sure latch bolt engages strike plate.
- 7. To adjust, loosen screws, re-position weatherstrip, and tighten screws.



The global leader in door opening solutions

Testing/Ratings:

Gasketing material for fire doors intended for aplication to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes. (Thresholds may or may

not contain gasketing material).





Tools Required:



www.pemko.com

MEMPHIS, TN USA P: 800 824-3018 F: 800 243-3656 VENTURA, CA USA VANCOUVER, BC CA P: 800 283-9988 P: 877 535-7888 F: 800 283-4050 F: 877 535-7444 TORONTO, ON CA P: 877 535-7888 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited. PG16_WEBINS Rev 5 - 01.24.17 Page 1 of 1