Architectural Door Accessories

Pemko Door Bottoms

Applies to the following door bottom:

346

Installation Instructions:

- 1. Install on frame over door.
- 2. Length should be equal to door width, plus 4" (2" each side).
- 3. Fasten with screws provided.
- 4. Be sure top of door clears raindrip when opened or closed.



The global leader in door opening solutions

Testing/Ratings:
Gasketing material for
fire doors intended for
aplication to listed steel
frames and/or classified
steel covered composite
type, and hollow metal
type fire doors rated
up to 3 hours; wood
and plastic covered
composite type fire
doors rated up to 1-1/2
hours; and wood core
type fire doors rated
up to 20 minutes.

(Thresholds may or may not contain gasketing material).



Tools Required:



www.pemko.com

MEMPHIS, TN USA P: 800 824-3018 F: 800 243-3656 VENTURA, CA USA VANCOUVER, BC CA P: 800 283-9988 P: 877 535-7888 F: 800 283-4050 F: 877 535-7444

TORONTO, ON CA P: 877 535-7888 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.