

# Architectural Door Accessories

**ASSA ABLOY**

## Pemko Door Bottoms

The global leader in  
door opening solutions


Applies to the following door bottom:

**3692\_PK772, 3692\_PK773**

### *Installation Instructions:*

1. To install, door must be removed.
2. Measure, mark and trim door bottom shoe to full width of door. Trim seal even with edges.
3. Fasten door bottom shoe to bottom of door with supplied screws.

### *Tools Required:*



[www.pemko.com](http://www.pemko.com)

MEMPHIS, TN USA    VENTURA, CA USA    VANCOUVER, BC CA    TORONTO, ON CA  
P: 800 824-3018    P: 800 283-9988    P: 877 535-7888    P: 877 535-7888  
F: 800 243-3656    F: 800 283-4050    F: 877 535-7444    F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.  
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

3692\_PK\_WEBINS  
Rev 2 - 03.07.17  
Page 1 of 1