

Pemko Brush Gasketing

The global leader in
door opening solutions

Applies to the following products:

5041_NB, 5041_SB, 5061_NB, 5025_NB, 5025_SB

Installation Instructions:

1. Remove brush from aluminum retainer.
2. Cut aluminum retainer to desired length.
3. Cut brush insert to fit aluminum retainer.
4. Route a 1/4" by 1/4" groove into the face or edge you intend to install the aluminum retainer.
5. Insert metal retainer into routed out groove.
NOTE: Secure retainer with a small brad at both ends of retainer for additional security if desired.
6. Slide the brush into the retainer.
NOTE: Metal channel for brush should have a slight wave to its shape to help retain the brush from slipping out of the aluminum retainer.

Tools Required:

