

Bed Box Mechanisms for Vertical Wall Bed

BE AWARE:
without the feet,
the metal frame mustn't be let down,
lower than 90° degree.

