
INSTALLATION INSTRUCTIONS

CONCEALED VERTICAL ROD EXIT DEVICE - NON-HANDED
SERIES 2600 , FL2600, 2600LBR & FL2600LBR




BOTTOM STRIKE SCREWS/ANCHORS	QTY.
1/4-20 x 1/2", FLAT HEAD MS	2
#14 X 1", FLAT HEAD SMS	2
ANCHOR, PLASTIC PLUG	2
DROP-IN ANCHOR, 1/4-20	2

FIRE EXIT DEVICES SERIES FL2600 & FL2600LBR
Sex bolts or through bolts are required for composite (Wood, Plastic and Steel covered), wood core, sheet metal and hollow metal doors without reinforcement unless door manufacturer has an alternate mounting method. Fire doors with steel reinforcement, mount devices with machine screws


NOTE:
Fire rated device with less bottom rod applications must use FIRE BOLT

CYLINDER ONLY INSTALLATION




1. Attach Cylinder Strap and Sleeves to the Rim Cylinder with (2) # 12-24 machine screws.
2. Insert Rim Cylinder thru Blocking Ring and outside hole as shown.
3. Postition Cylinder Back PLate on inside of door as shown centered in the hole in the door and with the cylinder tailpiece thru the hole in the backplate. Secure with (2) #8-32 machine screws provided.
4. The Cylinder Tailpiece should extend post the inside face of the door by 1/4" to 5/16".

DEVICE PREPARATION



CUT DEVICE: - If Required
1. Determine proper CHANNEL LENGTH by subtracting 1-11/16" from dimension Z.
2. Mark cut off point (hinge side filler must be all the way inside of channel).
3. Cut off channel and hinge side filler and deburr.



⚠ WARNING:
If your device is equipped with ALK, CD, DE, or DS then please refer to instruction sheet listed below prior to cutting the device.

ALK	Alarm Kit	01639-11-000
CD	Cylinder Dogging	01725-11-000
DE	Delayed Egress	01844-11-000
DS	Door Position	02187-11-000

- CAUTION -
PROTECT INSIDE OF DEVICE
FROM METAL SHAVINGS

CONCEALED VERTICAL ROD EXIT DEVICE - NON-HANDED
SERIES 2600 , FL2600, 2600LBR & FL2600LBR

STANLEY phi

DRWG	DATE	REVISION
01788-11-000	09/2014	C

Precision Hardware
a Division of Stanley Security Solutions, Inc.
www.stanleysecuritysolutions.com

1 DOOR PREPARATION

1. Circle the following
   BACKSET in the chart below.
   TRIM NO. (if specified) at various locations (holes B and C) on the TRIM TEMPLATE.


2. Mark HORIZONTAL CENTERLINE on inside face of door 39-15/16" from finished floor as shown. (Continue horizontal centerline to outside face of door if Trim is specified).

3. Mark VERTICAL CENTERLINE per BACKSET SCHEDULE at lock side on full height of door and carry it onto the under side of the DOOR STOP. (Mark vertical centerline at lock side using Backset dimension on outside face of door if Trim is specified).

CAUTION: Vertical centerlines on both sides of the door should be the same dimension from the edge of the door.

4. Tape LOCK STILE CASE, TOP LATCH and BOTTOM LATCH Templates (and Trim Template if Trim specified) to the door so that the centerlines on the Template line up with centerlines on the door. Mark centers and drill the required holes as indicated on the templates.


BACKSET SCHEDULE				
DOOR TYPE	ALUMINUM		HOLLOW METAL	
INSTALLATION	SINGLE DOOR	PAIR OF DOORS	SINGLE DOOR	PAIR OF DOORS
BACKSET	1-1/16"	1-1/16"	1-11/16"	1-11/16"
STILE WIDTH	1-3/4" MINIMUM	1-3/4" MINIMUM	3" MINIMUM	3" MINIMUM




REINFORCEMENT RECOMMENDED 5 PLACES. THE DOOR SKIN THICKNESS (INCLUDING REINFORCMENT) TO BE 1/8" - 5/32"

TOP STRIKE MACHINING

Door must be hung in the opening. Transfer the vertical centerline from the door to the frame rabbet and drill and tap the holes as shown.



4 DEADLOCK/HOLDBACK ADJUSTMENT



DEADLOCK:
When latchbolt is fully extended, it should be in deadlock. Deadlocking does not allow the latchbolt to be pushed down.

HOLDBACK: (Latches held retracted)
Top latch should be in holdback when the touchbar is depressed and door is open. If device is in holdback, the latchbolt cannot be extended without rotating the latchbolt. Make sure bottom bolt clears the bottom strike.

TO ADJUST HOLDBACK / DEADLOCK


HOLDBACK: If no holdback; turn top adjusting screw clockwise one half turn at a time and repeat if necessary

DEADLOCK:
Rotate top latchbolt to extend fully; if it is not deadlocked. Turn top adjusting screw counter clockwise one half turn at a time and repeat if necessary.

TO ADJUST BOTTOM BOLT

Depress the touch bar, the device must be in holdback to gain access to adjusting screw. To increase clearance between bottom bolt and strike , turn the bottom adjusting screw clockwise. To decrease clearance between the bottom bolt and strike, turn counter clockwise.

2 CVR ASSEMBLY & INSTALLATION



Thread top rod onto top rod connector to the DIM"A" as shown.

DOOR HEIGHT	DIM." A"
7'-0"	37'-11/16"
8'-0"	49-11/16"
9'-0"	61-11/16"
10'-0"	73-11/16"

For door heights not shown:
Add or subtract from DIM"A" shown.


NOTE:
All dimensions are based on the horizontal centerline of the device being mounted 39-15/16" from the finished floor. Adjust dimensions shown when the device is not mounted at that height.

Thread bottom rod onto bottom rod connector to the required dimension.
NOTE:
Bottom bolt must be fully extended

INSTALLATION

1. Insert Concealed Vertical Rod (CVR) assembly into the door through the hole in the top edge of door
2. Attach the CENTER CHASSIS to the door with two PILOT PINS through "E" holes. (see Device Template)
3. Attach each latch to the door with two screws and finishing washers.

BOTTOM BOLT APPLICATION



3 APPLY DEVICE

NOTE: If Trim is specified: see Trim instructions packaged with the trim.
If the Exit Device has Electrical or other options see specific option instructions packaged in exit device carton.

1. LOCK STILE CASE mounting
   DEVICE WITH TRIM: See trim instructions
   CYLINDER ONLY: See other side of instruction sheet

   Insert the SPINDLE in the CAM and attach the LOCK STILE CASE to the door with two screws.

2. Insert the MOUNTING BRACKET into touch bar assembly tight against the channel. Level the device, mark and drill 2 holes for #10 sheet metal screws or #10-24 machine screws. Fasten the MOUNTING BRACKET to door and attach the ENDCAP to MOUNTING BRACKET with 2 screws.

3. Attach Top Strike to frame using two screws. NOTE: If there is an excessive clearance between the door and frame, apply the strike shim.

4. APPLY BOTTOM STRIKE
   A. FOR FLOOR APPLICATION Center strike around bolt.
   - Mark floor for fasteners. Prepare floor for the type of fastener required. Provide clearance in floor for the bolt.

   B. FOR THRESHOLD APPLICATION - Center strike around bolt.
   - Provide hole in threshold to accept the bolt. Mark threshold for fasteners. Prepare the threshold according to the type of fasteners required.

5. Attach cover to Lock Stile Case with 2 screws.

