



1. Shut off power.
2. Remove cover and magnet assembly and discard the two screws.
3. Disconnect wire leads from power source to wire leads from magnet.
4. Assemble spacer (996511) behind cover and magnet assembly. Reconnect wire from magnet to power source.
5. Secure with two (2) #10-32 x 2-3/4" flat head self-tapping screws.

XK996 Extension Kit Parts List		
Qty.	Part No.	Description
1	996511	Spacer
2	01390244	10-32 x 2-3/4" Flat Head Self-Tapping Screw
3	998055	Junction Box Bracket

NOTES:

1. Do not scale drawing.
2. The XK996 Extension Kit is designed to increase the projection of models 997 and 998 wall mounted door releases by 1-1/2" (38mm)
3. A 13/64" (5mm) dia. drill must be used to enlarge the two (2) existing holes in the magnet mounting bracket assembly, when using XK996P with 997 or 998 models.
4. All dimensions given in inches (mm).

XK996 Extension Kit

RIXSON®

ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

DATE

DR100290

07-13