



Notes:

1. Do not scale drawing. Prepare door and frame per details shown.
2. Dimensions are given in inches (mm).
3. To insure proper operation of door, the centerline of the top pivot pin must be straight and plumb with bottom spindle.
4. Install jamb portion with pin retracted.
5. Install door portion.
6. Place door on bottom pivot and raise door to vertical position.
7. Engage top pivot pin by turning adjusting screw clockwise when door portion is in alignment with the jamb portion.

**340 Top Pivot
Center Hung Non Handed**

RIXSON®
ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

IS-340

DATE

07-09