Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

7800 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# 7057	Mounting Template	This can be used for indicator and strandard locks (Always Need This - Unless using Behavioral Health Trim)
Rose Trim Template Doc# 7058	Sectional/ Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
Dummy Trim Template Doc# 4298	Sectional/ Roses	Trim one side Kit Functions 93 & 94
50- Prefix Secured Indicator Rose Template Doc# 7682	Sectional Accessories/ Indicators	Includes 1- prefix, 74- prefix, & RX- Prefix || Available for the following functions: 24, 25, 26, 28, 29, 30, 36, 37, 38, 39, 40, 41, 43, 45, 50, 51, 52, 57, 58, 67 - with Rose Trim only
Thumbturn Template Doc# 7059	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
Sectional Indicator Template Doc# A7623	Sectional Accessories/ Indicators	**For 185c:** Functions and Roses available: • 30, 36 & 37 Functions with 7800, 8200 and R8200 locks, CR, L, LN, TR, E & O Roses • 26, 29, 38, 39, 40 and 41 Functions with 7800, 8200, and R8200 locks & LN Roses Only **For 185P:** Functions and Roses available: • 65, 66, 68 Functions with 7800, 8200, and R8200 locks, CR, E, L, LN, O & TR Roses
Sectional Indicator Template Doc# 4747	Sectional Accessories/ Indicators	For V series Indicators (V01, V20, etc) Functions: 7805, 7812, 7820, 7821, 7822, 7824, 7825, 7826, 7828, 7829, 7830, 7836, 7837, 7838, 7839, 7840, 7841, 7842, 7843, 7845, 7846, 7847, 7850, 7851, 7852, 7856, 7857, 7858, 7859, 7865, 7866, 7867, 7868, PHR-NAC-78285 "
LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template Doc# 7052	Escutcheon Trims	Exposed Screws
LE2, LE4, KE2, KE4 Trim Template Doc# 7052	Escutcheon Trims	Concealed Screws
LS & KS Trim Template Doc# 7054	Escutcheon Trims	Security Screws
WT Trim Template Doc# 7055	Escutcheon Trims	Surface Applied
VN1 Indicator Escutcheon Trim Template Doc# 4746	Escutcheon Indicators	Functions: 7805, 7812, 7820, 7821, 7822, 7824, 7825, 7826, 7828, 7829, 7830, 7836, 7837, 7838, 7839, 7840, 7841, 7842, 7843, 7845, 7846, 7847, 7850, 7851, 7852, 7856, 7857, 7858, 7859, 7865, 7866, 7867, 7868, NAC-PHR-78281, NAC-PHR-78285
PT Trim Template Doc# 4512	Behavioral Health (Anti-Ligature)	Functions: 7804, 7815, 7816, 7817, 7824, 7826, 7837, 7843, 7845, 7850, 7865
Curved/Straight Lip Strikes Doc# 7064	Strikes	
877 Open Back Strike Template Doc# 4744	Strikes	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Experience a safer and more open world

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

7800 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Main Installation Doc# A7772	Lockbody/Trim Related Installation Instructions	All Functions (Even Electrified)
Secured Indicator Rose and Retrofit Kit Installation Doc# A7671	Lockbody/Trim Related Installation Instructions	50- Prefix 185S Retrofit Kit
Anti Vandal Trim Installation Doc# A7635	Lockbody/Trim Related Installation Instructions	AV- prefix 667 Anti Vandal Trim Kit
Trim One Side Kit Installation Doc# A7028	Lockbody/Trim Related Installation Instructions	
Dummy Trim (One Side) Installation Doc# A7036	Lockbody/Trim Related Installation Instructions	7893 Function ONLY
7800 Knobs / 8200 Levers Mortise Lock & 3P8225 Levers Triad Lock with Escutcheon Trim - WT Designs Installation Doc# A7034	Lockbody/Trim Related Installation Instructions	
6300 Series Core Removal and Installation Doc# A5634	Cylinder/Thumbturn Related Instructions	Large Format Interchangable Core (LFIC)
130 Series Thumbturn and 184 Emergency Release Doc# A5675	Cylinder/Thumbturn Related Instructions	
Visual Occupancy Indicators Installation Doc# A7623	Sectional Indicators	185C, 185P and 49- Prefix
Electrified Functions and Monitoring Electrolynx Connector System Installation Doc# A7722	Electrical Related Instructions	Electrified Functions: 70,71, 72, 73 Monitoring Prefixes: RX, LX, DX
677 & 2-677 Rabbeted Door Kits Installation Doc# A7066	Misc. Instructions	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

7900 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# 4589	Mounting Template	This can be used for indicator and strandard locks (Always Need This - Unless using Behavioral Health Trim)"
IN Series Template Doc# 4713	Access Control	Functions: 7978, 7979
Rose Trim Template Doc# 7058	Sectional/ Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
Dummy Trim Template Doc# 4298	Sectional/ Roses	Trim one side Kit Functions 93 & 94
Thumbturn Template Doc# 7059	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template Doc# 7052	Escutcheon Trims	Exposed Screws
WT Trim Template Doc# 7055	Escutcheon Trims	Surface Applied
PT Trim Template Doc# 4512	Behavioral Health (Anti-Ligature)	Functions: 7804, 7815, 7816, 7817, 7824, 7826, 7837, 7843, 7845, 7850, 7865
Curved/Straight Lip Strikes Doc# 7064	Strikes	
877 Open Back Strike Template Doc# 4744	Strikes	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

7900 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Main Installation Doc# A8151	Lockbody/Trim Related Installation Instructions	IN120 and IN220
Main Installation Aperio Installation Doc# A8190	Lockbody/Trim Related Installation Instructions	
IN100 Series EM01 Outside Escutcheon & Controller Replacement Installation Doc# A8293	Electrical Related Instructions	
Door Position Switch Installation Doc# A7983	Electrical Related Instructions	FRAME ONLY
Door Position Switch Installation Doc# A8005	Electrical Related Instructions	HINGE ONLY
IN120 Passport 1000 P2 Series Wifi Enabled Installation Doc# WFMN10A	Electrical Related Instructions	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Experience a safer and more open world

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

8200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# 7057	Mounting Template	This can be used for electrical, indicator, and strandard locks (Always Need This - Unless using Behavioral Health Trim)
Electrified Lock Template Doc# 7065	Electrified	Typically paired with Main Lock Template Doc# 7057 (FOR FUNCTIONS 70 THRU 73) & (PREFIXES: 56-, RX-, LX- & DX-) & (NAC-270/271/274/275/280/281)
KP Series Template Doc# 4514	Access Control	Functions: 8276, 8277, 8278, 8279
SN Series Template Doc# 4702	Access Control	Functions: 82274, 82275, 82284, 82285, 82270, 82271, 82280, 82281
IN Series Template Doc# 4713	Access Control	Functions: 82276, 82277, 82278, 82279
Rose Trim Template Doc# 7058	Sectional/ Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL)
Dummy Trim Template Doc# 4298	Sectional/ Roses	Trim one side Kit Functions 93 & 94
Roseless Trim Template (R8200) Doc# 4647	Sectional/ Roses	Disontinued so this one is optional -- For RX- PREFIX, H1/H2 - & HT PREFIX, & Standard R8200
50- Prefix Secured Indicator Rose Template Doc# 7682	Sectional Accessories/ Indicators	Includes 1- prefix, 74- prefix, & RX- Prefix || Available for the following functions: 24, 25, 26, 28, 29, 30, 36, 37, 38, 39, 40, 41, 43, 45, 50, 51, 52, 57, 58, 67 - with Rose Trim only
Thumbturn Template Doc# 7059	Sectional Accessories/ Indicators	8203, 8205, 8212, 8221, 8222, 8223, 8224, 8225, 8228, 8243, 8245, 8247, 8250, 8251, 8256, 8257, 8258, 8265, 8266, 8267, 8268, NAC-(82280, 82281, 82284, 82285)
Sectional Indicator Template Doc# A7623	Sectional Accessories/ Indicators	**For 185c:** Functions and Roses available: • 30, 36 & 37 Functions with 7800, 8200 and R8200 locks, CR, L, LN, TR, E & O Roses • 26, 29, 38, 39, 40 and 41 Functions with 7800, 8200, and R8200 locks & LN Roses Only **For 185P:** Functions and Roses available: • 65, 66, 68 Functions with 7800, 8200, and R8200 locks, CR, E, L, LN, O & TR Roses
Sectional Indicator Template Doc# 4747	Sectional Accessories/ Indicators	**For V series Indicators (V01, V20, etc)** Functions: 8205, 8212, 8220, 8221, 8222, 8224, 8225, 8226, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8250, 8251, 8252, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, PHR-NAC-82281, PHR-NAC-82285"
LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template Doc# 7052	Escutcheon Trims	Exposed Screws

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

8200 Series Mortise Lock Templates (cont.)

Template Name & Doc Number	Category	Notes
LE2, LE4, KE2, KE4 Trim Template Doc# 7052	Escutcheon Trims	Concealed Screws
LS & KS Trim Template Doc# 7054	Escutcheon Trims	Security Screws
WT Trim Template Doc# 7055	Escutcheon Trims	Surface Applied
VN1 Indicator Escutcheon Trim Template Doc# 4746	Escutcheon Indicators	Functions: 8205, 8212, 8220, 8221, 8222, 8224, 8225, 8226, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8250, 8251, 8252, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, NAC-PHR-82281, NAC-PHR-82285
BHW Template Doc# 4711	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273, 82270, 82271, 82274, 82275, 82280, 82281, 82284, 82285
BHL Template Doc# 4745	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273
ALP Template Doc# 4745	Behavioral Health (Anti-Ligature)	Functions: 8204, 8205, 8206, 8213, 8215, 8216, 8217, 8224, 8225, 8226, 8227, 8228, 8229, 8230, 8231, 8235, 8236, 8237, 8238, 8239, 8240, 8241, 8242, 8243, 8245, 8246, 8247, 8248, 8249, 8250, 8251, 8252, 8255, 8256, 8257, 8258, 8259, 8265, 8266, 8267, 8268, 8270, 8271, 8272, 8273
Curved/Straight Lip Strikes Doc# 7064	Strikes	
Deadbolt Strike (78-0034) Doc# 7064	Strikes	Provided standard with deadlock functions 03, 20, 21, 22, 23, 28, 29, 30
877 Open Back Strike Template Doc# 4744	Strikes	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

8200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Standard Installation Doc# A7772	Lockbody/Trim Related Installation Instructions	All Functions (Even Electrified)
KP8200 Installation Doc# A7373	Acess Control Instructions	ONLY Use this when using the KeyPad
IN100 Aperio INstallation Doc# A8190	Acess Control Instructions	ONLY Use this when using the IN120 or IN220
IN120/IN220 Installation Doc# A8151	Acess Control Instructions	ONLY Use this when using the IN120 or IN220
SN Series Installation Doc# A8353	Acess Control Instructions	ONLY Use this when using the SN200 & SN220 Series Reader
Secured Indicator Rose and Retrofit Kit Installation Doc# A7671	Lockbody/Trim Related Installation Instructions	50- Prefix 185S Retrofit Kit
Anti Vandal Trim Installation Doc# A7635	Lockbody/Trim Related Installation Instructions	AV- prefix 667 Anti Vandal Trim Kit
Trim One Side Kit Installation Doc# A7028	Lockbody/Trim Related Installation Instructions	
Dummy Trim (One Side) Installation Doc# A7036	Lockbody/Trim Related Installation Instructions	8293 Function ONLY
7800 Knobs / 8200 Levers Mortise Lock & 3P8225 Levers Triad Lock with Escutcheon Trim - WT Designs Installation Doc# A7034	Lockbody/Trim Related Installation Instructions	
Studio Collection Levers Installation Doc# A7986	Lockbody/Trim Related Installation Instructions	
BHL Trim Installation Doc# A8131	Lockbody/Trim Related Installation Instructions	
BHD Trim Installation Doc# A8233	Lockbody/Trim Related Installation Instructions	
BHW Trim Installation Doc# A8146	Lockbody/Trim Related Installation Instructions	
Simpli™ Roseless Trim Installation Doc# A8030	Lockbody/Trim Related Installation Instructions	
Freewheeling Escutcheon Trim Installation Doc# A7334	Lockbody/Trim Related Installation Instructions	
Sectional Trim with V Series Indicator Installation Doc# A8257	Lockbody/Trim Related Installation Instructions	Outside: V10, V10F, V20, V20F, V30, V40, V50, V60 Inside: V01, V01F, V03, V04, V06 V10 + V01 = V11 (Same pattern applies across all other numbers)
VN1 Escutcheon Trim with V Series Indicator Installation Doc# A8260	Lockbody/Trim Related Installation Instructions	Outside: V10, V10F, V20, V20F, V30, V40, V50, V60 Inside: V01, V01F, V03, V04, V06 V10 + V01 = V11 (Same pattern applies across all other numbers)
130 Thumbturn 184 Emergency Release Installation Doc# A5675	Lockbody/Trim Related Installation Instructions	
Simpli™ Roseless Trim Installation Doc# A8030	Lockbody/Trim Related Installation Instructions	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Experience a safer and more open world



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

8200 Series Mortise Lock Installation Instructions (cont)

Installation Instructions Name & Doc#	Installation Category	Installation Notes
Freewheeling Escutcheon Trim Installation Doc# A7334	Lockbody/Trim Related Installation Instructions	FE Trim
Electrolynx Retrofit Kit Installation Doc# A7738	Electrical Related Instructions	
End-Of-Line Resistors for EcoFlex Mortise Locks Installation Doc# A8191	Electrical Related Instructions	
EcoFlex Electrified Mortise Locks With High Security Monitoring Installation Doc# A8192	Electrical Related Instructions	NAC- Trim
Electrified Functions and Monitoring Electrolynx Connector System Installation Doc# A7722	Electrical Related Instructions	Electrified Functions: 70,71, 72, 73 Monitoring Prefixes: RX, LX, DX
Full Wave Bridge Rectifier Wiring Diagram Doc# A6652	Electrical Related Instructions	
MELR Mortise Locks (Standard Levers)	Electrical Related Instructions	Motorized Electric Latch Retraction
MELR Mortise Locks (Studio Levers)	Electrical Related Instructions	Motorized Electric Latch Retraction
4399 Exit Button Installation Doc# A7864	Electrical Related Instructions	
Door Position Switch Installation Doc# A7983	Electrical Related Instructions	FRAME ONLY
Door Position Switch Installation Doc# A8005	Electrical Related Instructions	HINGE ONLY
Weather Seal Conduit Installation Doc# A7721	Electrical Related Instructions	52-2847
Controller Replacement Installation Doc# A8288	Electrical Related Instructions	52-6085
Weatherization Kit Installation Doc# A8289	Electrical Related Instructions	52-6084
IN100 Series EM01 Outside Escutcheon & Controller Replacement Installation Doc# A8293	Electrical Related Instructions	
IN120 Passport 1000 P2 Series Wifi Enabled Installation Doc# WFMN10A	Electrical Related Instructions	
IP-Enabled Quick Reference Guide Doc# WFMN3	Electrical Related Instructions	
6300 Series Interchangable Core Removal and Installation Doc# A5634	Cylinder Related	LFIC
KESO F1 Mortise and Rim Cylinders Removable Core Installation Doc# A5687	Cylinder Related	Mortise: 170 series Rim: 164 Series
677 & 2-677 Rabbeted Door Kits Installation Doc# A7066	Misc. Instructions	

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

9200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# 7057	Mounting Template	This can be used for electrical and strandard locks (Always Need This - Unless using Behavioral Health Trim)
Electrified Lock Template Doc# 7065	Electrified	Typically paired with Main Lock Template Doc# 7057 (FOR FUNCTIONS 70 THRU 73) & (PREFIXES: 56-, RX-, LX- & DX-) & (NAC-270/271/274/275/280/281)
Rose Trim Template Doc# 7058	Sectional/ Roses	Works for all Roses (O, CO, TO, LN, CR, TR, E2, E3, E4, L, SN, SL) 9200 Only
Dummy Trim Template Doc# 4298	Sectional/ Roses	Trim one side Kit Functions 93 & 94
Main Lock Template Doc# 4482	Mounting Template (Optional - Read Notes)	This is to be used with one side trim kit Functions 93 & 94
Thumbturn Template Doc# 7059	Sectional Accessories/ Indicators	7805, 7812, 7824, 7825, 7828, 7843, 7845, 7847, 7850, 7851, 7856, 7857, 7858, 7865, 7866, 7867, 7868, NAC-(78280, 78281, 78284, 78285)
LE1, LE3, LW1, CE, TE, KE1, KE3, KW1 Trim Template Doc# 7052	Escutcheon Trims	Exposed Screws
LE2, LE4, KE2, KE4 Trim Template Doc# 7052	Escutcheon Trims	Concealed Screws
LS & KS Trim Template Doc# 7054	Escutcheon Trims	Security Screws
WT Trim Template Doc# 7055	Escutcheon Trims	Surface Applied
BHW Template Doc# 4711	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9206, 9215, 9216, 9217, 9224, 9225, 9226, 9235, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
BHD Template Doc# 4745	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9215, 9216, 9217, 9224, 9225, 9226, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
Curved/Straight Lip Strikes Doc# 7064	Strikes	
877 Open Back Strike Template Doc# 4744	Strikes	

9200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category
9200 with Rose Trim Installation Doc# A7146	Lockbody/Trim Related Installation Instructions
KS and LS Escutcheon Trim Installation Doc# A7147	Lockbody/Trim Related Installation Instructions
130 Thumbturn and 185 Emergency Release Installation Doc# A5675	Lockbody/Trim Related Installation Instructions

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25

Experience a safer and more open world

Mortise Lock



SARGENT
ASSA ABLOY

Template and Installation Instruction Guide

91065

M-9200 Series Mortise Lock Templates

Template Name & Doc Number	Category	Notes
Main Lock Template Doc# 4483	Mounting Template	M- 9200 Only
Rose Trim Template Doc# 7058	Sectional/Roses	Works for Roses: (L, LN, SN, SL) M- 9200 Only
Thumbturn Template Doc# 7059	Sectional Accessories/Indicators	Functions: 9203, 9205, 9221, 9222, 9223, 9224, 9225, 9243, 9245, 9250, 9265, 9266
LE3 Trim Template Doc# 7052	Escutcheon Trims	
LE4 Trim Template Doc# 7052	Escutcheon Trims	Concealed Screws
LS Trim Template Doc# 7054	Escutcheon Trims	Security Screws
BHD Template Doc# 4745	Behavioral Health (Anti-Ligature)	Functions: 9204, 9205, 9215, 9216, 9217, 9224, 9225, 9226, 9237, 9238, 9239, 9240, 9241, 9242, 9243, 9245, 9249, 9250, 9255, 9259, 9265, 9266, 9270, 9271, 9272, 9273
Curved/Straight Lip Strikes Doc# 7064	Strikes	
877 Open Back Strike Template Doc# 4744	Strikes	

M-9200 Series Mortise Lock Installation Instructions

Installation Instructions Name & Doc#	Installation Category
9200 with Rose Trim Installation Doc# A7146	Lockbody/Trim Related Installation Instructions
KS and LS Escutcheon Trim Installation Doc# A7147	Lockbody/Trim Related Installation Instructions
130 Thumbturn and 185 Emergency Release Installation Doc# A5675	Lockbody/Trim Related Installation Instructions

Copyright © 2025, Sargent Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited. 02/25