

# Architectural Door Accessories

**ASSA ABLOY**

## Pemko Door Bottoms

The global leader in  
door opening solutions

Applies to the following door bottom:

**317\_N, 317\_P, 318\_V, 3185\_V, 310, 311CIN**

### *Installation Instructions:*


#### DOOR BOTTOMS:

1. Measure, mark and trim door bottom shoe to full width of door. Trim seal 1/16" longer than trimmed door shoe at each end. Crimp ends to secure insert.
2. Notch both ends to clear stops.
3. Slide door bottom shoe in place and close door. Position so that it makes light even contact with the threshold. Mark door in center of slotted holes.
4. Drill pilot holes in door at marks.
5. Secure door bottom shoe to door with supplied screws. Adjust to ensure light even contact with threshold.

#### ASTRAGALS & MEETING STILES:

1. Trim lengths equal to door height.
2. Position at meeting stile edge of doors so that seals slightly overlap. Install screws in center of slots.
3. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.

### *Tools Required:*



[www.pemko.com](http://www.pemko.com)

MEMPHIS, TN USA	VENTURA, CA USA	VANCOUVER, BC CA	TORONTO, ON CA
P: 800 824-3018	P: 800 283-9988	P: 877 535-7888	P: 877 535-7888
F: 800 243-3656	F: 800 283-4050	F: 877 535-7444	F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.  
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DB21\_WEBINS  
Rev 2 - 03.07.17  
Page 1 of 1