

The images are showing the following steps:

1. We choose the place where we want the hook to be installed and we mark with a pencil where we want to drill the screws holes. Ensure the bracket is straight.
2. Drill the holes and place the plastic anchors in. Make sure the plastic anchors are flush with the wall.
3. Position the bracket and tighten the screws
4. Place the hook base over the bracket and tighten with the Allen screw on the bottom.

FR
Les images nous décrivent les étapes suivantes :

1. Choisissez l'endroit ou le crochet doit être installé et utiliser un crayon pour indiquer les trous de vis. Assurez-vous que la plaque d'installation est droite.
2. Percez les trous et introduisez les chevilles en plastique. Assurez-vous que les chevilles sont placées au ras de mur.
3. Placez la plaque et serrez les vis.
4. Placez le crochet sur la plaque et serrez la vis Allen qui se trouve en bas du crochet.

SP

Las imágenes muestran los siguientes pasos:

1. Elija el lugar donde quiera instalar el gancho y marque los agujeros para tornillos. Asegúrese de que el soporte quede recto.
2. Taladre los agujeros y coloque los anclajes de plástico. Asegúrese de que los anclajes queden enrasados con la pared.
3. Posicione el soporte y apriete los tornillos.
4. Inserte el gancho en el soporte y apriete el tornillo Allen de la parte inferior del gancho.