



LHR SHOWN
RHR OPPOSITE

CX9875/9975 & CX9875-F/9975-F Series
Mortise Lock Device (Wood Door)

VON DUPRIN®

NOTES: SEE MASTER SHEET #10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER:

W10351_a

DATE:
05-29-13

NOTE: MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR

FOR OUTSIDE TRIM PREPARATION, WHEN REQUIRED, SEE ADDITIONAL TRIM TEMPLATE

REMOVE GLASS STOP OR BEAD IN AREA OF DEVICE IF REQUIRED UNLESS GBK IS USED.

WIRING FOR E7500 & SS7500 LOCKS: GO THRU DOOR AND NOT DEVICE. MINIMUM RACEWAY CLEARANCE IS 1 1/4"