


REMOVAL AND INSTALLATION INSTRUCTIONS

Item No. 433,19,047

Depth Adjustment Fitting

Depth Adjustment (+4.5 mm forward)



Adjust Left and Right adjustment screw simultaneously in opposite directions



Removal





Removal - Remove existing standard fitting.

Insertion





Insertion - Insert depth fitting.

Screwdriver is required for removal of the standard fitting.