Standard trims

	EO	NL	TP	DT	K	L
	Exit only	 **Night latch** Key retracts latchbolt	 Key locks thumbpiece	 **Dummy trim** Pull when dogged	 Key locks knob	 **Key locks lever** #06 Standard
Product description	88EO	88NL	88TP	88DT	88K[1,2,3]	88L[1,2,4,5,6,7]
Trim description	—	880NL-R	880TP-R	880DT-R	880K-R	373L
Escutcheon plate size	—	3" x 14 3/16" x 3/32"	3" x 14 3/16" x 3/32"	3" x 14 3/16" x 3/32"	3" x 14 3/16" x 3/32"	3" x 14 3/16" x 3/32"
Grip mounting center	—	5 1/2"	5 1/2"	5 1/2"	—	6 1/4"
Projection	—	2"	2"	2"	2 3/4"	2 5/8"
ANSI function	01	03	05	02	08	08/09
Cylinder type	—	Rim	Rim	—	Rim	1 1/4" Mortise
Sex bolt quantity #425 (optional)	8	4	4	4	4	4

Optional trims

	NL	TP	DT	K	EO
	 **Night latch** Key retracts latchbolt	 Key locks thumbpiece	 **Dummy trim** Pull when dogged	 Key locks knob	 **Exit only**
Product description	88NL x 608NL	88TP x 608TP	88DT x 608DT	88K x 606K[1,2,3,5]	88L x 880EO
Trim description	608NL-R	608TP-R	608DT-R	606K-R	880EO-R
Escutcheon plate size	1 5/8" x 13 1/2" x 3/16"	1 5/8" x 13 1/2" x 3/16"	1 5/8" x 13 1/2" x 3/16"	1 5/8" x 8 3/4" x 3/16"	3" x 14 3/16" x 3/32"
Grip mounting center	5 1/2"	5 1/2"	5 1/2"	—	—
Projection	2 1/6"	2 1/6"	2 1/6"	2 3/4"	—
ANSI function	03	05	02	08	01
Cylinder type	Rim	Rim	—	Rim	—
Sex bolt quantity #425 (optional)	NR	NR	NR	NR	4

[1] If no cylinder operation is required, specify "BE" blank escutcheon, trim always operable; example 88TP-BE.
[2] Matching dummy trim available,use suffix "DT"; example 88K-DT.
[3] Night latch function available, order 88NL x 880K-R rigid.
[4] When using sex bolts, an 889 cover plate is required. See page 24.
[5] When using on wood doors without sex bolts, "WDA" cover plate is required. See page 24.
[6] Not available with E88.
[7] The 373L is shipped L. An NL cylinder plate is also furnished standard (for operation only when key is used).
NR-Not recommended

Notes