



70243 - Rubber Switch Cover

For Push-Button Switches



FEATURES:

- Protects Switches from Moisture & Debris
- Built-in Nut Base
- Rubber Switch Cover Fits Push Button Switches
- Does Not Fit Long Travel Switches
 - Designed for 70200 & 70210
- Clear Cover