Bottom-mount Waste Bin 624 Series



6245910 Model: 1 x 30L




6246910 Model: 2 x 14L



6247910 Model 3 x 10L

Applications

- Base cabinet
- Under-sink cabinet
- Any room in the house



Style and function!

Description

Sliding waste bin with bottom mounting, designed for hinged door cabinets – convenient and discreet for a well-organized kitchen.

Features

- Trendy dark grey color
- Available in 3 different models: 1 bin of 30 L, 2 bins of 14 L, 3 bins of 10 L
- Bottom-mounted with just a few screws
- Designed for automatic opening (attached to the cabinet door), but can also be used for manual opening – see installation specifications on the next page
- Fixed inner lid
- Bins and frames made of plastic, with ball-bearing slides
- Each bin has handles for easy grip; the handles also help keep bags in place

Advantages - Benefits

- Compact sliding waste bin, ideal for small spaces
- Full-extension slides provide complete access for easy bag changes
- Fixed inner lid prevents odors from spreading when the bin is full
- Sturdy lower frame ensures system stability
- Fixed lid doubles as an additional storage shelf
- Trendy dark grey color blends seamlessly with your kitchen décor
- Durable base withstands frequent opening and closing
- Very easy to install in manual opening mode
- One-motion access with door-mounted (automatic opening) installation

Code	Description	Finish	Product Width	Product Depth	Product Height
6245910	BOTTOM MOUNT WASTE BIN 1X30L	DARK GRAY	260mm (10 5/16")	452mm (17 25/32")	442mm (17 13/32")
6246910	BOTTOM MOUNT WASTE BIN 2X14L	DARK GRAY	260mm (10 5/16")	452mm (17 25/32")	442mm (17 13/32")
6247910	BOTTOM MOUNT WASTE BIN 3X10L	DARK GRAY	260mm (10 5/16")	452mm (17 25/32")	442mm (17 13/32")

Bottom-mount Waste Bin 624 Series

These waste bins can be installed either with automatic opening (using an opening arm attached to the door) or with manual opening (without using the door-mounted arm).

IMPORTANT:

- Installation dimensions vary depending on whether the product is installed for automatic or manual opening – see the table below
- For the automatic opening version, use the template provided in the box
- For the manual version:
    - Simply position the trash can at the bottom of the cabinet, allowing clearance for hinges if needed
    - Mark the drilling points and screw the frame into the cabinet base
    - Do not use the provided template

Installation Type	Installation width required	Installation depth required	Installation height required
Automatic opening	358mm (14 1/8'')	453mm (17 7/8'')	443mm (17 ½'')
Manual opening	262mm (10 3/8'')	472mm (18 9/16'')	443mm (17 ½'')

Manual installation:

