69 - HINGE PIN DOOR STOP

IVES

IVES® hardware has provided style and durability for American homes since 1876. Our commitment to quality makes IVES a name you can trust.

HINGE PIN DOOR STOP


FOR USE ON REMOVABLE PIN-HINGED TYPE DOORS TO STOP DOOR AND PREVENT DAMAGE TO DOOR, WALL AND DOOR KNOB. FEATURES REMOVABLE BUSHING TO ACCOMMODATE LARGE HINGE PINS.

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Regular screwdriver and hammer.

1. Using screwdriver and hammer, carefully remove pin (A) from hinge.
2. Position door stop on top of hinge and tap hinge pin (A) into hinge using hammer. If hinge pin (A) is too large, remove bushing (B) by loosening bolt (C); retighten.
3. To adjust for desired degree of opening, loosen adjustment bolt (C) and slide stop arm (D). Retighten bolt.

NOTE: Two hinge pin door stops are recommended per door.



ASK FOR OTHER FINE HARDWARE BY H.B. IVES


WINDOW LOCKS


DOOR STOPS


COAT & HAT HOOKS



DOOR BOLTS

0 44074 00741 1

HINGE PIN DOR STOP C69F3 BRASS

MADE IN U.S.A.