



Functions

Description		Outside Lever		Inside Lever	
Function & Diag.(ANSI No.)	Latch operated by	Locked by	Unlocked by	Locked by	Unlocked by
Double keyed (Continued)					
Storeroom* (G) F91 	Rotating the outside lever when not locked by key Rotating the inside lever when not locked by key	Turning the key in the inside lever Turning the key in the outside lever	Turning the key in the inside lever Turning the key in the outsidelever	Turning the key in the inside lever Turning the key in the outside lever	Turning the key in the inside lever, Turning the key in the outside lever
	Turning the key in either the inside or the outside, locks or unlocks both sides.				
Intruder (IN) F11 	Rotating inside lever, Rotating outside lever only when not locked by inside or outside key	Turning key in the inside lever Turning the key in the outside lever	Turning key in the inside lever, Turning the key in the outside lever	Cannot be locked	Always unlocked
Communicating* (S) F80 	Turning the key in the inside lever Turning the key in the outside lever Rotating the inside or outside lever (if unlocked)	Turning the key in the outsidelever	Turning the key in the outside lever	Turning the key in the inside lever	Turning the key in the inside lever
	Turning the key in either lever, locks or unlocks its own lever independently..				
Communicating* (W) F87 	Turning the key in the inside lever Turning the key in the outside lever	Always fixed	Cannot be unlocked	Always fixed	Cannot be unlocked
Keyless					
Privacy (L) F76 	Rotating the inside lever Rotating the outside lever only when the inside push button is out	Pushing the inside button	Rotating the outside slotted button Rotating the inside lever Closing the door.	Cannot be locked	Always unlocked
Passage (N) F75 	Rotating the inside lever Rotating the outside lever	Cannot be locked	Always unlocked	Cannot be locked	Always unlocked
Exit (NX) F89 	Rotating the inside lever	Always fixed	Always fixed	Cannot be locked	Always unlocked
Patio (P) F77 	Rotating the inside lever Rotating the outside lever only when the inside push button is out	Pushing the inside button	Rotating the inside lever Closing the door	Cannot be locked	Always unlocked
Exit (Y) 	Rotating the inside lever			Cannot be locked	Always unlocked
Single Dummy Trim (1DT) 	This is a single, surface-mounted lever for an inactive door or a non-latching door				

*ATTENTION: Locksets that secure both sides of the door are controlled by building codes and the Life Safety Code. In an emergency exit situation, failure to quickly unlock the inside knob could be hazardous or even fatal.