This operation guide describes the basic functions of your GT Series Tenant Station

For a complete operation manual (4.2 MB), scan QR code or use link to download it from the manufacturer's website: **www.aiphone.com/gt-1m-l_op-man**

AIPHONE®




GT-1M-L Tenant Station

Power Source

This tenant station is powered by the system and will always remain on, even when the screen is off. Contact the building manager if the tenant station in this residence is not working.

T-Mode Hearing Aid Compatible

This tenant station emits an electromagnetic field, producing clear audio for T-Mode compatible hearing aids.



Option Button



Push the option button to activate an external device (if included).

Guard Button



Push the guard button to call all guard and concierge stations connected to the system (if included). To view a visitor on a CCTV camera (if enabled), push the guard button while in communication with the entrance station.

LCD Screen

Handset

Pick up the handset to answer an incoming call. Hang up the handset to end a call.

Door Release Button



Push the door release button to unlock the entrance during a call.

Tone Off Indicator Light

Chime Speaker

LCD Screen Brightness Control



Use the switch to adjust the LCD screen brightness levels (dark, moderate, or bright).

Chime Volume Control



Use the switch to adjust the chime volume (off, medium, or high). The tone off indicator light blinks slowly when the chime is muted.