
I-LS01977

LFIC TAILPIECE & CORE INSTALLATION

STEP 1:

INSERT TAILPIECE AND INSTALL RETAINING CAP


Hager Core Requires Both Washers



STEP 2:

ROTATE CONTROL KEY 15° CW & INSTALL INTO LEVER.

DO NOT FORCE INTO LEVER! IF CORE DOES NOT FULLY INSERT, REMOVE, CHECK TIMING AND TRY AGAIN.



NOTE: FOLLOW TIMING INSTRUCTIONS (IF APPLICABLE) BEFORE INSTALLING CORE.

Rev 1, Rev Date: 1/25/17 27390091