T2 – DL2700 Programming - Cheat Sheet

Factory Code = 12345

1. ***Change Factory code to the new Master code. (Must be 3-5 digits in length.)***

1 2 3 4 5	**A_L**	**1**	**A_L**		**A_L**	
				(Enter Master Code)		***(Re Enter Master Code)***

2. ***Create Manager Code*** ***(Code length must be the same as the master code)***

Master Code	**A_L**	**2**	**A_L**	
				(Enter Manager Code)

3. ***Add User Code(s)***

Bank 1 *(Code length must be the same as the master code)*

User 1	Master or Manager code	**A_L**	**11**	**A_L**	
User 2	Master or Manager code	**A_L**	**12**	**A_L**	
User 3	Master or Manager code	**A_L**	**13**	**A_L**	
User 4	Master or Manager code	**A_L**	**14**	**A_L**	
User 5	Master or Manager code	**A_L**	**15**	**A_L**	
					(Enter User Code)

Bank 2

User 1	Master or Manager code	**A_L**	**21**	**A_L**	
User 2	Master or Manager code	**A_L**	**22**	**A_L**	
User 3	Master or Manager code	**A_L**	**23**	**A_L**	
User 4	Master or Manager code	**A_L**	**24**	**A_L**	
User 5	Master or Manager code	**A_L**	**25**	**A_L**	
					(Enter User Code)

Bank 3

User 1	Master or Manager code	**A_L**	**31**	**A_L**	
User 2	Master or Manager code	**A_L**	**32**	**A_L**	
User 3	Master or Manager code	**A_L**	**33**	**A_L**	
User 4	Master or Manager code	**A_L**	**34**	**A_L**	
User 5	Master or Manager code	**A_L**	**35**	**A_L**	
					(Enter User Code)

4. ***1 Time Code*** (Replaces Bank 3 User 5)

Master or Manager code	**A_L**	**3**	**A_L**	
				(Enter User Code)

5. ***Passage Mode***

Master Code	**A_L**	**4**	**A_L**

6. ***Re-Lock***

Master Code	**A_L**	**5**	**A_L**

7. ***Disable Banks***

Bank 1	Master or Manager code	**A_L**	**51**	**A_L**
Bank 2	Master or Manager code	**A_L**	**52**	**A_L**
Bank 3	Master or Manager code	**A_L**	**53**	**A_L**

8. ***Re-Enable Banks***

Bank 1	Master or Manager code	**A_L**	**41**	**A_L**
Bank 2	Master or Manager code	**A_L**	**42**	**A_L**
Bank 3	Master or Manager code	**A_L**	**43**	**A_L**

9. ***Disable/Re-Enable Individual User(s)***

Master or Manager code	**A_L**			**A_L**
		(Bank #)	(User #)	