

80 Series

Template and Installation Instruction Guide

91059

8300 Series Exit Device Templates

Template	Function
Metal Door Device Template (Includes 12 Prefix) 4310	8304, 8310, 8313, 8315, 8328, 8340, 8343, 8344, 8363, 8373, 8374, 8375, 8376
Wood Door Device Template 4709	8304, 8310, 8313, 8315, 8328, 8340, 8343, 8344, 8363, 8373, 8374, 8375, 8376
700 Series ET Trim Template 4277	8304, 8310, 8313, 8315, 8340, 8343, 8344
700 Series ET Trim Template 4314	8373, 8374, 8375, 8376
FLL Trim Templates 4257	8304, 8310, 8328, 8363
FLW Trim Templates 4257	8304, 8310, 8328, 8363
MAL Trim Templates 4024	8304, 8310, 8328, 8363
PTB Trim Templates 4221	8304, 8328, 8363
PTB Trim Templates 4222	8310
STS Trim Templates 4020	8304, 8310
STS Trim Templates 4021	8328, 8363


Options

Template	Prefix
See above	12
Consult Technical Product Services 4568	31
4314	53, 55, 56, 58, 59, AL
	54

Thermal Pin Template
[4617](#)

Options

Template	Strike
4192	815
3908	908, C908



80 Series

Template and Installation Instruction Guide

91059

8300 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Main Device Installation Doc# A6696	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
668 Glass Bead Shim Kit Installation Doc# A7955	Accessory Related Instructions	For narrow stile devices
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059

8400 Series Exit Device Templates

Template	Function
Aluminum Door (AD Prefix) Device Template 4312	8406, 8410, 8413, 8415, 8440, 8443, 8446, 8473, 8474
Metal Door (MD Prefix) Device Template (Includes 12 Prefix) 4447	8406, 8410, 8413, 8415, 8440, 8443, 8446, 8473, 8474
700 ET Trim Template 4448	8406, 8410, 8413, 8415, 8440, 8443, 8446,
700 ET Trim Template 4467	8473, 8474
862, 863, 864 Trim Template Field Prep	8410
P106/P113 Auxiliary Control Template 4212	8410

Options

Template	Prefix
See above	12
Consult Technical Product Services	31
4568	53, 55, 56, 58, 59, AL
4467	54
4312 , ref note 9	NB

Template	Strike
4449	606, 650, 652
4649	640
4386	881




80 Series

Template and Installation Instruction Guide

91059

8400 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
106/113 Aux Control Installation Doc# A5985	Device/Trim Related Instructions	
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
668 Glass Bead Shim Kit Installation Doc# A7955	Accessory Related Instructions	For narrow stile devices
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059

8500 Series Exit Device Templates


Template	Function
8500 Device Template 4307	8504, 8510
8500 Device Template 4645	8506, 8510, 8513, 8515, 8540, 8543, 8544, 8546, 8573, 8574
700 ET Trim Template 4414	8504, 8504, 8506, 8510, 8510, 8513, 8515, 8540, 8543, 8544, 8546
700 ET Trim Template 4530	8573, 8574
862, 863, 864 Trim Template MEDT35	8504
Cylinder Prep 4645	8504
700-8 Trim Template 4645	P706-8, P713-8, P715-8, P740-8, P743-8, P744-8, P746-8
700-8 Trim Template 4529	P773-8, P774-8

Options

Template	Prefix
See above	12
Consult Technical Product Services	31
4568	53, 55, 56, 58, 59, AL
4529	54

Template	Removeable Mullion
4311	650A

Template	Strike
4308	657
4386	881
3996	644
3995	603, 613
4309	658
4007	632, 642
4004	649
4309	656




80 Series

Template and Installation Instruction Guide

91059

8500 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Main Device Installation Doc# A6699	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
Anti Vandal Trim Installation Doc# A5030	Device/Trim Related Instructions	821, 824, 826, 827 Included
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
668 Glass Bead Shim Kit Installation Doc# A7955	Accessory Related Instructions	For narrow stile devices
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059


8600 Series Exit Device Templates

Template	Function
Aluminum Door (AD Prefix) Device Template 4661	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
Metal Door (MD Prefix) Device Template (Includes 12 Prefix) 4445	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
Metal Door (NB-MD Prefix) Device Template (Includes 12 Prefix) 4566	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
Metal Door (HC-MD Prefix) Device Template (Includes 12 Prefix) 4566	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
Wood Door (WD Prefix) Device Template (Includes 12 Prefix) 4413	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
Wood Door (NB-WD Prefix) Device Template (Includes 12 Prefix) 4565	8606, 8610, 8613, 8615, 8640, 8643, 8646, 8673, 8674
700 ET Trim Template 4448	8606, 8613, 8615, 8643, 8646
700 ET Trim Template 4436	8610, 8640
700 ET Trim Template 4467	8673, 8674
862, 863, 864 Trim Template Field Prep	8610
P106/P113 Auxiliary Control Template 4212	8610
SN200, SN210 Reader Controller 4704	8673, 8674

Options

Template	Prefix
See above	12
Consult Technical Product Services	31
4569	53, 55, 56, 58, AL
4467	54
4455	59
(See above)	NB

Template	Strike
4449	606, 650, 652
4649	640
4386	881



80 Series

Template and Installation Instruction Guide

91059

8600 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Wood Door Installation Doc# A3937	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
Metal Door Installation Doc# A7002	Device/Trim Related Instructions	Hollow Metal and Aluminum
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
106/113 Aux Control Installation Doc# A5985	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
Glass Bead Shim Kit Installation Doc# A6710	Accessory Related Instructions	537, 587, 589 Shim kits
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059

8700 Series Exit Device Templates

Template	Function
8700 Device Template 4289	8706, 8710, 8713, 8715, 8728, 8740, 8743, 8746, 8762, 8763, 8773, 8774
12- Prefix 8700 Device Template 4297	PE8706, PE8710, PE8713, PE8715, PE8728, PE8740, PE8743, PE8746, PE8762, PE8763, PE8773, PE8774, PE8778
Metal & Wood Door Device Template (Includes NB & 12 Prefix) MEDT13	8706, 8710, 8710, 8713, 8715, 8728, 8740, 8743, 8746, 8762, 8763, 8773, 8774
NB-8700 Device Template (Includes 12- Prefix) <i>Old Template for devices ordered prior to 04/14/25</i> 4559	8706, 8710, 8713, 8715, 8728, 8740, 8743, 8746, 8762, 8763, 8773, 8774
Metal Door (FM & HC, HC4 Prefix) Device Template (Includes 12 Prefix) 4462	8706, 8710, 8713, 8740, 8746, 8773, 8774
700 ET Trim Template 4277	8706, 8710, 8713, 8715, 8740, 8743, 8746
FLL/FLW Trim Template 4257	8706, 8713, 8728, 8762, 8763
MAL Trim Template 4024	8706, 8713, 8728, 8762, 8763
PTB Trim Template 4222	8706, 8713
PTB Trim Template 4220	8728, 8762, 8763
STS Trim Template 4021	8706, 8713, 8728, 8762, 8763
862, 863, 864 Trim Template Field Prep	8710
Auxiliary Control Template 4214	306, 313
SN200, SN210 Reader Controller for (12-) 8700 4705	8773, 8774

Options

Template	Prefix
See above	12
Consult Technical Product Services	31
4569	53, 55, 56, 58, 59, AL
4314	54
(See above)	NB

Template	Strike
4009	624
4004 / 4413	646
4225	648
4413 / 4296	653
4296	654
4004 / 4413 / 4296	655
4296	659
4387	881

Template	Trim
4414	704, 706-8, 710, 713, 715, 740, 743, 744, 746, 773, 774
4529	(54-) 773, (54-) 774




80 Series

Template and Installation Instruction Guide

91059

8700 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Main Device Installation Doc# A6701	Device/Trim Related Instructions	Standard, Fire Rated (12-), Hurricane Rated (HC/HC4) Included
FM8700 Installation Doc# A7827	Device/Trim Related Instructions	Fire Rated (12-) Included
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
306/313 Auxiliary Control Installation Doc# A5978	Device/Trim Related Instructions	
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
Glass Bead Shim Kit Installation Doc# A6710	Accessory Related Instructions	537, 587, 589 Shim kits
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059

8800 Series Exit Device Templates

Template	Function
8800 Device Template (Includes 12-, WS, 12-WS Prefixes) 4415	8888, 8804, 8806, 8810, 8813, 8815, 8840, 8843, 8844, 8846, 8873, 8874, 8875, 8876, 8877, 8878
8800 Device Template (Includes 12-, WS, 12-WS Prefixes) 4285	8816, 8828, 8863, 8866
8800 Device Template (Includes 12-, WS, 12-WS Prefixes) 4286	8893
8800 Device Template (Includes 12-, WS, 12-WS Prefixes) 4466	8895
HC-8800 Device Template (Includes 12- Prefix) 4465	8804, 8810, 8840, 8844
HC-8800 Device Template (Includes 12- Prefix) 4463	8806, 8813, 8815, 8843, 8846
700 ET Trim Template (Excludes HC-8800 Devices) 4277	8873, 8874, 8875, 8876
FLL / FLW Trim Template 4257	8804, 8810, 8828, 8863, 8866
FSL/FSW/PSB Trim Template 4546	8804
MAL Trim Template 4224	8828, 8863, 8866
PTB Trim Template 4220	8828, 8863, 8866
STS Trim Template 4021	8828, 8863, 8866
821, 826 Anti- Vandal Trim 4554	8804
862, 863, 864 Trim Template 4307	8804
SN200, SN210 Reader Controller 4707	8873, 8874, 8875, 8876
IN100, IN120, IN220 Reader Controller 4716	8877, 8878


Options

Template	Prefix
See above	12
Consult Technical Product Services	31
4569	53, 55, 56, 58, 59, AL
4530	54
4474	KP

Template	Strike
3995	603,613
4007	632, 642
3996	644
4004	649
4417	656
4308	657
4309	658
4386	881

Template	Removable Mullion
MEDT78	650A
4715	980/L980, 980A/L980A, 12-980/12-L980, EL980
MEDT39	HD/HC/HCL980 (includes 12-), SM980/SML980
4206	SMEL980

Template	Trim
4414	706-8, 713-8, 715-8, 740-8, 743-8, 744-8, 746-8
4530	(54-) 773-8, (54-) 774-8, (54-) 775-8, (54-) 776-8




80 Series

Template and Installation Instruction Guide

91059

8800 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Main Device Installation Doc# A6770	Device/Trim Related Instructions	Standard, Fire Rated (12-), Windstorm Rated (WS), Hurricane Rated (HC) Included For all functions EXCEPT 16, 28, 63, 66
Main Device Installation Doc# A6703	Device/Trim Related Instructions	Standard, Fire Rated (12-), Windstorm Rated (WS), Hurricane Rated (HC) Included ONLY for functions: 16, 28, 63, 66
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
814 Pull Trim installation Doc# A5025	Device/Trim Related Instructions	814-FSL, 814-MSL, 814-PSB, 814-FSW For use on 8804 ONLY
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
Glass Bead Shim Kit Installation Doc# A6710	Accessory Related Instructions	537, 587, 589 Shim kits
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	



80 Series

Template and Installation Instruction Guide

91059

8900 Series Exit Device Templates


Template	Function
8900 Device Template (Includes 12-,WS, 12-WS Prefixes) 4709	8904, 8906, 8910, 8913, 8915, 8916, 8928, 8940, 8943, 8944, 8946, 8963, 8966, 8973, 8974, 8975, 8976, 8977, 8978
Wood Door Device Template 4290	8904, 8906, 8910, 8913, 8915, 8916, 8928, 8940, 8943, 8944, 8946, 8963, 8966, 8973, 8974, 8975, 8976, 8977, 8978
700 ET Trim Template 4277	8904, 8906, 8910, 8913, 8915, 8916, 8940, 8943, 8944, 8946
700 ET Trim Template 4314	8973, 8974, 8975, 8976
FLL / FLW Trim Template 4257	8904, 8910, 8928, 8963, 8966
MAL Trim Template 4024	8904, 8910, 8928, 8963, 8966
PTB Trim Template 4020	8963, 8966
PTB Trim Template 4220	8928
PTB Trim Template 4221	8904
PTB Trim Template 4222	8910
STS Trim Template 4020	8904, 8910,
STS Trim Template 4021	8928, 8963, 8966
Anti-Vandal Trim 4554	8904, 8910
SN200, SN210 Reader Controller 4708	8973, 8974, 8975, 8976
IN100, IN120, IN220 Reader Controller 4717	8977, 8978

Options

Template	Prefix
MEDT42	12
Consult Technical Product Services	31
4569	53, 55, 56, 58, 59, AL
4314	54
4477	KP

Template	Strike
4192	815
3908	908, C908

4617	Thermal Pin Template
----------------------	-------------------------



80 Series

Template and Installation Instruction Guide

91059

8900 Series Exit Device Installation Instructions

Installation Name & Doc#	Installation Category	Installation Notes
Main Device Installation Doc# A6705	Device/Trim Related Instructions	Standard, Fire Rated (12-), Windstorm Rated (WS) Included For all functions
Through Bolt (TB) Installation Doc# A6257	Device/Trim Related Instructions	Standard and Fire Rated (12-) Included
700 Series ET Trim Installation Doc# A6374	Device/Trim Related Instructions	Standard Trims Functions: 04, 06, 10, 13, 15, 73, 74, 75, 76
700 Series ET Trim Installation Doc# A7261	Device/Trim Related Instructions	Freewheeling Trims Functions: 40, 43, 44, 46
54- Lever Monitor & Electrified Trim Installation Doc# A7725	Device/Trim Related Instructions	773, 774, 775, 776 & 54- lever wiring
862/863/864 Pull Installation Doc# A7474	Device/Trim Related Instructions	
16- and 816 Kit Installation Doc# A6848	Accessory Related Instructions	
Glass Bead Shim Kit Installation Doc# A6710	Accessory Related Instructions	537, 587, 589 Shim kits
43- Flush End Cap Installation Doc# A7581	Accessory Related Instructions	
565/665 End Cap Installation Doc# A6924	Accessory Related Instructions	
541 Security Shim kit Installation Doc# A8008	Accessory Related Instructions	
AL Alarm Installation Doc# A7224	Electrical Related Instructions	
55- Signal Switch Installation Doc# A6808	Electrical Related Instructions	
855 Signal Switch Kit Installation Doc# A7110	Electrical Related Instructions	To retrofit 55- Request to exit Signal Switch into an 80 series rail
53- Latchbolt Monitoring Installation Doc# A7678	Electrical Related Instructions	
58- Electric Dogging Installation Doc# A6835	Electrical Related Instructions	
59- Delayed Egress Installation Doc# A7690	Electrical Related Instructions	
56- ELR Installation Doc# A7925	Electrical Related Instructions	
R56/M56 Electric Latch Retraction Kit Installation Doc# A7926	Electrical Related Instructions	
55-56 Kit Installation Doc# A6912	Electrical Related Instructions	