# Large Format Interchangeable Core Cylinders

Access 3®

## Interchangeable Core

For use with Corbin Russwin's 6-pin Interchangeable Core housings & shells.*



*CR8700 core must be used with 1078 or 3078 housings to maintain UL437 listing

| Type | Finish |
|---|---|
| CR8500 - AP Type<br>CR8600 - AS Type<br>CR8700 - AHS Type | 606 and 626 only |

Note: All plugs and shells for LFIC cylinders are provided in 606 or 626. Mortise and rim housings are provided in the finish of the lock hardware order

## Driver Assemblies

For use with LFIC cores



**LFIC**



**CL3300**



**CL3100**

| Part No. | Driver Type |
|---|---|
| 631F188 | Driver, LFIC (114) |
| 631F198 | Driver, LFIC (138) |
| 631F208 | Driver, LFIC (112) |
| 631F215 | Driver S/A LFIC (134) |
| 631F238 | Driver, CL3300 Series |
| 631F258 | Driver, CL3100 Series |

## *How to Order Examples*

### AS Security Interchangeable Core Ordered Separately

| Quantity | Keyset | Cylinder | Keyway | Finish |
|---|---|---|---|---|
| 50 | AA1 | CR8600 | CRA1 | 606 |



Copyright © 2013-2019, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.