


# FIRST CHOICE BUILDING PRODUCTS

## INSTALLATION GUIDE FOR 8860 MORTISE LOCK EXIT DEVICE

(LEFT-HAND DOOR SHOWN)



### INSTALLATION STEPS:


1. ADJUST MOUNTING POSTS (SEE DETAIL VIEW) ON MORTISE LOCK ASSY SO THAT FACE PLATE SITS FLUSH TO FACE OF LOCK-STILE.
2. SECURE MORTISE LOCK TO INTERIOR OF STILE USING #10-32 X 1 7/8" SCREWS.
3. SCREW END CAP SUPPORT BRACKET TO HINGE-STILE USING 1/4-20 PAN HEAD SCREWS, LEAVING 1/8" GAP BTWN BRACKET AND STILE. (SEE STEP 4)
4. ALIGN SLOTS IN PUSHBAR CHANNEL WITH INSTALLED SCREWS (FROM STEP 3), AND SLIDE CHANNEL BEHIND SUPPORT BRACKET.
5. DEPRESS LATCH BOLT ON MORTISE LOCK ASSY, AND INSERT CYLINDER OF CHANNEL END BLOCK THROUGH HOLE IN LOCK-STILE AND INTO MORTISE LOCK. CAM LINK SHOULD BE ORIENTED AS SHOWN (IN DETAIL VIEW) INSIDE MORTISE LOCK ASSY.
6. SECURE CHANNEL END BLOCK TO LOCK-STILE USING 1/4-20 X 5/8" FLAT HEAD SCREWS. (TO ALLOW CLEARANCE FOR INSTALLING BOTTOM SCREW, DEPRESS THE PUSHBAR.)
7. SECURELY TIGHTEN 1/4-20 PAN HEAD SCREWS. (FROM STEP 3)
8. INSERT FILLER BAR INTO REAR OF CHANNEL, AND SECURE FILLER BAR END CAP TO SUPPORT BRACKET USING #8-32 X 1/2" FLAT HEAD SELF-TAPPING SCREWS.
9. SECURE PUSHBAR END CAP TO PUSHBAR USING #8-32 X 1" FLAT HEAD SELF-TAPPING SCREWS.
10. INSTALL MORTISE LOCK FACE PLATE USING #8-32 X 1/4" FLAT HEAD SCREWS
11. CAREFULLY SECURE STRIKE CUP **ORIENTED AS SHOWN** TO INTERIOR OF DOOR JAMB USING #10-32 X 1/2" FLAT HEAD SCREWS.
12. SECURE STRIKE PLATE **ORIENTED AS SHOWN** TO STRIKE CUP USING #10-32 X 1/2" FLAT HEAD SCREWS.

**FIRST CHOICE**  
BUILDING PRODUCTS

REVISED: 3/16/2015

# FIRST CHOICE BUILDING PRODUCTS DOOR & JAMB PREP FOR 8860 MORTISE LOCK EXIT DEVICE

(LEFT-HAND DOOR SHOWN)



	BACKSET	DOOR FRAME OPENING WIDTH			
		30"	36"	42"	48"
DIM "A"	31/32"	27.314	33.314	39.314	45.314
	<b>1 1/8"</b>	<b>27.158</b>	<b>33.158</b>	<b>39.158</b>	<b>45.158</b>
	1 1/2"	26.783	32.783	38.783	44.783

**FIRST CHOICE**  
BUILDING PRODUCTS

REVISED: 1/22/2015